



C4 Rear Tow Mount

DK-10

1. After removing the rear spring for coilovers you can mount our rear tow mount hooks.
2. You must insert the upper bolt through the bracket first then install loosely in the differential.
3. Install the lower bolt but do not tighten
4. Tighten upper bolts to 35 ft lbs or torque to yeild if using an open end wrench.
5. Tighten lower bolts to 35 ft lbs or torque to yeild if using an open end wrench.
6. Repeat on other side.



You must insert the bolt through the bracket first

WARNING: Tow hooks should NOT be used during transportation. Tightening a vehicle from the chassis can cause shock/suspension failure.



Tighten upper bolts first