



C4 Smart Struts

SS-03K, SS-08K

1. Models with dual exhaust will most likely have to drop the axle back portion of the exhaust. Check for clearance of the inner bucket bolts.
2. Measure from the lower inner bracket bolt to the outboard bolt on both sides to get your alignment back as close as possible.


LH measurement _____

RH measurement _____

3. Remove the outboard mount bolts on the spindle.
4. Remove the inboard bracket bolts from the differential removing the bracket and the struts rods together.
5. Install the inboard smart strut brackets utilizing the OE hardware to the differential.
6. Pick your setting for how you drive your Corvette. Top setting is track, bottom setting is drag racing. Upper middle is advanced street, bottom middle setting is standard street.
7. Install the inboard strut rod with new hardware provided on your preferred setting.
 - a. *poly kits will have reducing washers that must go between the bushing and the bracket on each inboard bushing.*
 - b. *HD spherical kits will have 1/2" ID inboard spacers that will fill in the bracket.*
8. Install the outboard side to the knuckle reusing OE hardware.
9. Set strut rods to the measurements you wrote down above.
10. Double check jam nuts and all hardware is



5



7b



8