

63-82 T-Arm Poly Bushing Washer



1. Remove old rubber bushings and shells. If replacing poly, just remove bushings
2. Thoroughly lubricate bushings with provided silicone
3. Insert bushings and then the sleeve that has one washer already installed
4. Brace the backside of the bushing so you can install the second washer.
5. Using a small ballpin hammer, you can flare the sleeve onto the washer.
6. Check to make sure the washer doesn't spin, then you know it is installed correctly.

The photos show the flaring of the shell onto the washer that is already installed for you. It'll be the same once installed with the bushings into the trailing arm.