

1985-96 Corvette Front Brake Adaptors for C5 or C6 Z06 Caliper

Bracket to Caliper

- 2 M14-2.00 x 35mm Allen Socket Bolt, Grade 12.9
- 2 M14 Nord Lock Washers

Bracket to Adapter

- 2 M14-2.00 x 40mm Allen Socket Bolt, Grade 12.9
- 2 M14 Nord Lock Washers

****Torque All Bolts to 125 ft. lbs**

****Use Red Loc-tite**

****Re Torque after 50 miles of driving and again after 1000 miles**

NoteFB-306K Kits will ONLY use 35mm bolts**

1985-96 Corvette Front Brake Adaptors for C5 or C6 Z06 Caliper

Bracket to Caliper

- 2 M14-2.00 x 35mm Allen Socket Bolt, Grade 12.9
- 2 M14 Nord Lock Washers

Bracket to Adapter

- 2 M14-2.00 x 40mm Allen Socket Bolt, Grade 12.9
- 2 M14 Nord Lock Washers

****Torque All Bolts to 125 ft. lbs**

****Use Red Loc-tite**

****Re Torque after 50 miles of driving and again after 1000 miles**

NoteFB-306K Kits will ONLY use 35mm bolts**