

*It's normal to have an air gap above the bushings and below the sombero mount on the frame. You'll notice the OE bushing is even lower than the delrin.*



**3D exploded view:**

*Orientation is set as would be in the car. The thick part of the bushing should go up into the frame mount. Make sure to check that your crossmember needs the washer between the bushing and the SG-47 plate*

