

Delrin Spring Adjuster Instructions

Smooth A-Arm spring pockets of any burs. Thread bolt through spring and apply red loc-tite to Delrin. Be sure the bolt is threaded the correct way before applying loc-tite.