



GB-BORG-RB

Borgeson Reinforcement Bracket

Provided hardware:

- Steering Box Brace
- 3/8" - 16 x 4.5" x 3
- 3/8" Flat Washer x 6
- 3/6-16 Nyloc Kut x 3
- M10-1.5x30mm Flange Head x 2
- M10 Lock Washer x 2

Start by checking clearance of the inner fender and the top of the steering box, you may want to remove the inner fender for better access to the top of the steering box.

- 1** Remove and discard the two inner most bolts on top of the steering box, new hardware is provided.
- 2** If the box is already installed on the car, remove the 3 frame mount bolts and retain your factory hardware. You can also use the 4.5" long bolts provided in the kit if you no longer have your factory bolts.

Using the factory or provided hardware, install the three frame mount bolts but do not tighten.

Install the top mount bolts to secure the bracket to the steering box torquing them to 37 ft lbs.

Tighten the frame mount bolts to 35-40 lbs and your steering box is now ready for the track or the street.

