

Tap holes with supplied tap to clean threads. Apply loctite each bolt. Evenly tighten and torque to 35-40 ft/lbs. HD cap will hit half shaft at full droop. This is normal. When the car is on jack stands you can lift the trailing arm up to install the caps. When the car is on the ground, there should be no interference.