



Half Shaft Flange U-Joint Warning



The Half Shaft flange can bend during install. You must secure the flange before pressing out and pressing in the u-joint. We recommend bolting it to your spindle flange.



1-800-418-5397 • 727-561-9199 • vansteel@vansteel.com • [facebook.com/vansteelcorvettes](https://www.facebook.com/vansteelcorvettes) • [instagram/vansteelcorvettes](https://www.instagram.com/vansteelcorvettes)